MACHINE UPDATE NOTICE

New Canister Change Procedure A3

This machine has been updated to the A3 NEW procedure. Before performing your next canister change, please read this notice and contact AMT Support.

STOP · ACTION REQUIRED

Contact AMT Support before starting the canister change.

Your machine **must be switched over to the A3 NEW procedure on our side** before the first canister change. Do not begin the procedure until support has confirmed the switchover.

THE A3 CANISTER CHANGE

Change both canisters as a 1:1 pair.

1

Remove

When the HMI prompts, disconnect the quick-release (QR) connectors and remove the spent FA and the full RA canister.

→

2

Replace (1:1)

Fit a fresh FA326 (full) and an empty RA326 with the QR connectors. The system runs closed-loop, 1:1.

→

3

Return

Re-pack the used canister in its barrel with vermiculite and return it to AMT as hazardous waste.

KEY POINT

Both canisters are changed together every time, at a 1:1 ratio. The closed-loop system has no interim tank to drain, so each change is a simple paired swap.

CONTACT AMT SUPPORT

support@amtechnologies.com

See the attached process summary for full details, or reach out to your AMT account manager.