CANISTER CYCLE

PROCESS AT CUSTOMER SITE



1

Drain Interim Tank
Pump liquid into empty RA canister



2

Normal Operation
Machine operates with FA



3

Shipment Arrives
3× FA (10l) + 1× RA (EMPTY)

DETAILED CANISTER REPLACEMENT PROCESS

Every 3 FA canister changes, the bubbling tank must be emptied into an empty RA canister. The steps below are inserted into the standard canister replacement process.

OPERATOR INSERTS AN EMPTY RA CANISTER

MACHINE FILLS RA CANISTER WITH WASTE LIQUID FROM BUBBLING TANK

AUTOMATIC MACHINE OPERATION OPERATOR INTERACTION REQUIRED

FUTURE ORDERS - STANDARD SHIPMENT



3× FA 326 (10L)



1×EMPTY RA 326 (10L)